






**Note:** The primary circuit and parts of the other circuits are slightly different from this diagram in other areas, therefore please see the schematic diagrams shown on the back page.





# IMPORTANT

## The Voltage Selection and Fuse Replacement of this set.

(Note the indication of primary fuse(s))

Although this set is pre-set for the use on your area's AC line voltage without any re-adjustment, it can be used on all AC voltages in the world through following adjustments.

To change the voltage, remove a voltage selector cover located on the rear panel near the power cord or on the chassis base inside the enclosure, and replace the plug so that its arrow coincides with the required voltage marked on the selector socket. Do not forget to replace the fuse as well with one of appropriate capacity.

The AC line voltage

	100V – 120V	200V – 240V
Use a . . . . .	0.25A fuse	0.2A fuse
	0.5A fuse	0.2A fuse
	0.8A fuse	0.5A fuse
	1 A fuse	0.5A fuse
	1.2A fuse	0.8A fuse
	2.3A fuse	1.2A fuse
	3.3A fuse	1.8A fuse
	4.0A fuse	2.3A fuse
	5.0A fuse	2.3A fuse
	6.0A fuse	3.3A fuse

